


Adjusting the barrier arms



Adjust the barrier arm on the valley side, as shown on the photo.



Adjust the cam on the barrier arm on the hill side as shown on the photo.



Adjust the stop screws on the barrier arms, as shown on above photos.